

尺寸：140x85mm

200克铜板纸 双面印四色 封面封底过哑胶 20P钉本

Home use smart projector



✂ Quick installation guide ✂

Thank you for choosing this wireless LED Pico Projector. This projector offers 150 ansi lumens with built-in battery and has Android built in and screen mirroring.

The projector offers simple easy wireless mirroring with most devices including Apple, Android and Windows laptops, games consoles and other devices.


Safety Instructions

1. Do not look at the lens when the projector is running as the light glare may damage your eyes
2. The voltage for this product is only in the range of 100V-240V and cannot be adjusted exceed this range.
3. The battery for this product is only internal and must not be tampered with
4. Do not use your projector in areas with static electricity or where they may come into contact with moisture as it may cause malfunction and damage to the projector.
5. Do not block the vents while the projector is turned on especially the vents at the bottom of the device as it may cause overheating, damage or fire.
6. Please store this device at the optimum temperature of 0 to 35 °C or a working temperature of -10 to 35 °C, If you do not intend to use the product for a long time please store it fully charged, and discharge it at least once every 3 months to prevent any reduction in the battery performance.
7. Improper use of the projector and/or failure to read this user manual may lead to serious bodily injury. Seller will take no responsibility for any injuries caused by improper use without following the manual.

Directory


Specifications	02
Projector Settings	03
Remote Control	04
Power ON/OFF	05
Network setting	05
Bluetooth setting/Language setting	06
Application setting/Restore factory setting	07
Projection setting	08-09
Setting-Audio setting/Time setting	10
Other setting	11
EShare Instruction for Android	12-13
Eshare Iphone device user guider iPhone	14
Eshare Windows device user guider	15
Whats in the box	16
Warranty Card	17

Specification




CPU	ARM cortex-a7
RAM	2GB
ROM	16G
Wifi	2.4G / 5G
Display Technology	DLP Technology
Lens	High lens head
LED light	RGB
Physical Resolution	1920*1080/4K
Projection Image Size	40-300 Inch
Wireless Mirroring	0.5-8m
Adjustment Function	Keystone Correction / Manual Focus
System	Android 7.1
Bluetooth	Bluetooth 4.0
Remote control	Infrared remote control
Speaker	Stereo Speaker , 4Ω3W
Power	AC100-240V , 50 / 60HZ , DC12V / 3A
Ports	HDMI/USB3.0/USB2.0/TFcard/3.5mm Earphone Jack / DC in
Dimensions	close:120*128*63.5mm open:120*128*96mm

Projector Settings



Remote Control




When enter into youtube, netflix etc video apps, you need switch to cursor module.

Power ON/OFF

1. When the power switch on the bottom of the machine is set to "ON", the machine will rise up and then turn on.
2. Turn the power switch on the bottom of the machine to "OFF", and the machine will turn off and then descend.
3. After the bottom switch is turned on, Panel printed with finger silk screen position also can turn on/off with pressing and holding for 2 seconds.
4. When it isn't use for a long time, please turn the bottom power switch to the "OFF" state to avoid the battery from draining quickly.
5. When press Reset button, Please turn the bottom "ON/OFF" button to off so the reset button Effective.


Network setting

Wi-Fi Setting Refresh Wi-Fi




Setting -Network Setting -WIFI Setting, turn on WIFI; Select the wireless network in the Wifi list and enter the password to connect.

Bluetooth setting




Setting -Bluetooth setting, turn on Bluetooth, click refresh device, and search for device pairing success.

Application setting




Settings-other setting-application setting, enter the application setting to manage the APP of the machine.

Language setting




Setting-Language Setting, enter the language setting to set the language and input method switching.

Restore factory setting




Setting-Other setting-Restore factory setting, click OK to restore to factory setting.


Projection setting




1. Setting -projector setting -wind speed adjustment, you can manually adjust the fan according to the use of the projector to accelerate heat dissipation.




2. Projection mode: user can choose different projection mode in accordance with different placing way. This machine supports front projection, rear projection, upside down before projection and upside down after the projection.



3. Keystone correction: user can choose auto keystone correction and manual keystone correction.




4. Brightness setting, user can adjust it based on personal needs.




5. Color temperature. User can adjust it based on personal needs.

Audio setting



Setting-Audio setting,use remote controller or touch screen to adjust sound volume.

Time setting




Use remote control or touch screen to choose Settings - Time and Date, user can change the settings of time and date.

Other setting

1.HDMI mirror screen . Select the HDMI icon on the interface and press OK then switch to HDMI mode.



2.User can check the contents of U-disk in removable disks of File Explorer after insert U-disk. User can use remote control or long-press mouse to copy, paste, delete, move or rename files.




EShare Instruction for Android

1. Install EShare App on Android Device

- ① Please make sure that Android device and projector are connecting with same network.
- ② Run " EShare Server" on projector side and operate according to the tips on the screen. Scanning QR code or visiting download website with Android smart phone, downloading and installing "EShare for Android".

- a. Connect your cellphone to network "same network connected to the projector"
- b. Visit "EShare download link" in explorer or scan QR code
- c. Open EShare, then click "Device name".



2. Connect Projector with Android Device

When EShare installation is finished, run "EShare" on smart phone side, then EShare will search for the projector which shares the same network with it automatically, click device list on the top to search again and check device. Click objective device name on the device list and the connection will be built. Projector will connect with device automatically when there is only one device available in EShare side.

3. Wireless File Transfer

You can transfer selected files including music, video, pictures, office documents, PDF, e-book or APK from your Android devices to Projector by clicking "Storage".

4. Wireless Control!

Click this icon in the EShare, then the smart phone can be used as the mouse, remote controller, keyboard or fly mouse of the projector.

5. TV Mirror


Click this icon in the EShare, you can transmit pictures from projector to smartphone in real-time.

6. Mirroring

Click this icon on the smartphone, you can transmit the screen of Android device to projector screen.

7. Camera

Click this icon in the EShare, pictures and sound of the smartphone camera can be transmitted to the projector in real-time.



Remote



TV Mirror




Mirroring




Camera

EShare iPhone instruction

1. Slide iPhone screen from bottom to top, click AirPlay mirror, then choose device in the list to achieve sharing screen with iPhone.



- ① Install EShare App on iOS Device (Open App Store on iPhone or iPad);
- ② Search "EShare" and install "EShare for iPhone/iPad".



3. Connect Projector with Android Device

- ① Connect your cellphone to network "same network connected to the projector"
- ② Visit "EShare download link" in explorer or scan QR code with cellphone to download and install the app.



EShare Instruction for Windows

EShare Windows instruction



1. Install EShareApp on Windows Device

- ① Please make sure that Windows device and projector are connecting with same network.
- ② Run "EShareServer" on the projector and operate following the tips on the screen. Input download address in Explorer address bar, download and install "EShare for Windows".

- a. Connect your cellphone to network "same network connected to the projector"
- b. Visit "EShare download link" in explorer or scan QR code with cellphone to download and install the app.
- c. Open EShare, then click "Device name".


2. Connect with Projector

Run "EShare" app, then EShare will search for the projector which share the same network with it automatically. When EShare find the device, click projector name on the device list to build the connection.



Whats in the box


the box contents include a Remote Control, a Power Supply Unit(PSU),HDMI, User manual and the Projector.




Projector




Remote Control



Power Adapter



HDMI



User Manual

Warranty Card

Problem occurred:

Customer's Info.:

Name:

Telephone:

Address:

All pictures and function descriptions in the product manual are based on the actual product and factory preset contents. The company is committed to continuously improving product performance and strengthening product functions. The company reserves the right to improve the product functions and interfaces described in this book without prior notice. The right to notice is subject to the final physical object.

Please keep your device properly. The company is not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. The company also has no responsibility for any loss of any third-party.

This manual has been carefully reviewed by professional engineer, but there are inevitable some omissions. Thanks for your understanding.

Attention: when projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain if your eyes are close to the lens. Children should use the projector under the supervision of adults.